





AdvancedLive

Discover how AdvancedLive will help you...



AdvancedLive lets you view and control elements of your site's fire system anywhere, anytime, on any internet-enabled device – for day-to-day reassurance that your system is working as intended.

If problems do occur, they are clearly flagged as they occur and recorded in an easy access-log – for complete fire safety peace of mind.

<p>Access and security:</p>  <ul style="list-style-type: none"> • Gain quick, easy access to your fire system from any browser-enabled device, using your personal login • Easily invite new users, revoke access, view user status and set permissions – for complete control of who does what on the system • Flexible login methods give you fast, secure access without the need to remember yet another password! • Automatic link timeout for added security • Individual logins let you track individual actions taken on AdvancedLive – all stored in comprehensive log 	<p>Live monitoring:</p>  <ul style="list-style-type: none"> • Closely follow fire incident developments and make safer, informed decisions on the go • A clear, intuitive dashboard shows device status and duration of isolations/enabements • Choice of map or list view to suit your needs and budget • Clear colour coding for easy identification of panels, devices and status • Maximum response time thanks to a clear view of first and second-stage investigation countdown (where set up on your fire system) • Easy to view and navigate different floors of multi-storey buildings for quick identification of areas needing your attention
<p>Notifications:</p>  <ul style="list-style-type: none"> • Be the first to know about critical incidents with instant text alerts to your mobile upon fire alarm • Miss nothing with status-change alerts via text message during incidents – quickly see first and subsequent detections, investigation delay start and end points and reset actions • Immediate, secure AdvancedLive access via instant text notification link upon alarm 	<p>Control:</p>  <ul style="list-style-type: none"> • Save time by setting and ending isolations on your chosen devices without needing to be at the panel • Remotely acknowledge and extend the fire alarm investigation period (where set up on your fire system) • Avoid unwanted alarms by remotely isolating devices before resetting the system at the panel
<p>Clear device information:</p>  <ul style="list-style-type: none"> • Enjoy quicker, easier testing of devices in alarm, with less scope for accidental activations • Quick-access panel and device history aids fire system event analysis by showing types of detection and actions taken • See device information including type, state, zone, loop, address, analogue value and key dates e.g. last tested, isolated etc. • Get complete history of each device on your fire system • Clearly see relationship between devices such as sounder and beacon 	<p>Floor plans (optional):</p>  <ul style="list-style-type: none"> • View zone and device location and status, colour coded to flag Fire, Fault, Isolation and OK • Real-time updates, without refreshing your browser • Click to select individual device details • Easy pinch-to-zoom map view with full screen option • Easily plot new and unmapped devices by dragging them to the required position • Hovering over device symbols reveals additional information about them • Easy identification of paired output device elements – one symbol represents all inputs and outputs in an I-O unit and clicking reveals how it's made up e.g. sounder/beacon, optical smoke detector etc.